This Page Is Inserted by IFW Operations and is not a part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

As rescanning documents will not correct images, please do not report the images to the Image Problem Mailbox.

					•		
				•			
_			•				
			•		,		
						•	
		•					
<i>.</i>			n ka				
	•						

Warning

ELECTRICAL SHOCK HAZARD. Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the off position before removing or installing any thermostat.

Warning

This thermostat must be installed only by a professional contractor familiar with air conditioning and heating systems controls and wiring.


Install only on 24V AC control systems

Rocalman

9720

DELUXE PROGRAMMABLE THERMOSTAT

instruction confront solutions



7 Day Programmable

3 Heat / 2 Cool

HEAT PUMP



Intelligent Comfort Control

The 9720 has your comfort in mind. Our programmable thermostat is full of intelligent leatures, providing the ultimate choice in flexibility. Customize your surroundings. In QuickSet mode, set seven daily programs for summer and winter all at once. Choose Auto Changeover, and the thermostat will automatically switch to heat or coot, keeping you comfortable year round. These smart features enable you to control your comfort level and reduce energy costs up to 25%.

The 9720 is compatible with all standard 24 Volt AC multi-stage heat / cool systems, up to 3 stage heat, 2 stage cool. Multi-colored LED's indicate system status with Auxiliary (green), Check (red), and Emergency Heat (red).

When you select a Robertshaw thermostal, you've made the choice of an industry partner that's been making quality products for 100 years. Come home to affordable comfort. Come home to Robertshaws.

Features and Benefits

NiteView Backlight Display

Backlight display can be easily activated by pressing buttons or convenient light bar.

Auto Changeover

Automatically switches into heat or cool mode. Prevents having to manually change system from heat to cool.

7 Day Programming

Seven separate daily programs with four time and lemperature changes per day allow maximum flexibility.

Battery Back-Up

Prevents loss of programming due to power outages. QuickSet^{IM}

Allows 7 days to be programmed all at once. **EER!* (Energy Efficient Recovery)**

Increases energy savings. EERTH allows gradual recovery from setback temperature to minimize use of auxiliary systems.

Automatic Compressor Short Cycle Protection A system safeguard: Reduces wear and tear of HVAC equipment.

Remote Sensor Capable

Remote sensor capable - averages up to 4 sensor

Toll-Free Assistance

Toll-Free Technical Service number printed right on the thermostat provides immediate assistance. Adjustable Temperature Differential Maintains optimal customer comfort. Duick Wire Terminal Block

Fast and easy installation. Uses sturdy wire clamps no wrap-around of screws.

Filter Monitor

Indicates when filler needs to be cleaned or replaced. Programmable Fan

Energy cost savings. Allows user to set and provide continuous circulation for optimal comfort.

remote sensur capable


Remote sensor capable — averages up to 4 sensor inputs (including main). Remote sensors are available separately as model 9015.

Temporary Program Override


Allows for manual temperature adjustment.

Programmable Keypad Lock


Eliminates tampering. Keeps others from changing desired program.




Click here to purchase



7 Day Programmable 3 Heat / 2 Cool





Optional Accessory: 9015 REMOTE SENSOR

THE ROBERTSHAW 9720 REPLACES:

Maple Chase	09720
White-Rodgers Company*	1F92, 1F94
Honeywell, Inc.*	T8611G

^{*} Verify specific application requirements before substitution.

Shipping Information

Indiv. Ctn. Dim.: 7.75* x 4.75* x 1:875* :Master Ctn. Otv.: 6

Master Ctn. Dim.: 10.25" x 6.5 x 8.25"

Master Cin. Cu. Ft.: 32 Master Cin. Wt.: 8.5 lbs. Max. Pallet Qty.: 720

Max. Pallet Wi - 1020 lts.

Item 9015 Remote Sensor

Indiv. Ctn. Dim.: 4:375" x 2.525" x 1.375"

Master Cin. City.: 6

Master Ctn. Dim.: 5.625" x 4.875" x 4.875"

Master Cm. Cn. Ft. 08

Master Ctn. Yrt.: 1.0 bs.

Specifications

Terminal Designations

Electrical rating: 24 Volt AC (18-30 VAC)

1.5 ampination made per terminal (relay pulputs)

4 ampitotal maximum load (all terminals combined)

Tomperature control range: 45 / 52 F (7/ 32 C)

Accuracy: 4/ 5 T (4/-2°C)

Auto-changeover deadband: Selectable T or 5T

DC power: 3.0 Volt CC (4 "AA" alkaline batteres included!

Temporary temperature override: 4 hour maximum or next setposit Remote sensor capable: Averages up to 4 sensor inputs

(3) remote plus main sensort

System configurations: Multi-stage Leat pump systems 10p to 3 stage heat; 2 stage conf.

Other Multi-Stage

Architectural / Engineering Specification

The theorical shall be a Robertshaw Moder 9770 or equivalent. The theoricant shall have severe day program matality with up to 4 time/lamparature changes per day The theorical will ellow temporary temperature override for a maximum of 4 hours or the past subject time, whichever notices that. The theorical setting for both liest and second stage operation to a law efficient system operation. The themostal shall allow the user to program the system has separately for continuous or automatic operation for each of the 4 time setting for day to pred forest application and cool requirements. The themostal shall be equipped with an admittable for dulary or break top to 20 security during the rooting made for maximum comfort and efficiency.

If shall be capable of operating with standard 24 VAC multi-stage leat pump systems, up to 3-stage lieat, 2-stage cost. The thermoscet will have an electrical rating of 1.5 amp managing hold our leading of 1.5 amp managing hold our leading to the thermostat shall have relay outputs compatible with standard 24 VAC countd curvifs and have bettery back-up to prevent loss of programming in memory during power outages. The baltury hack-up circuit shall maintain all user programming for at least three months.

Other Multi-Stage *** Heat / Cool Thermostats

9520 Digital Mon-Programmonile HP 42 3 4 9620: Programmonie - Day HF

Uni-Line North America 515 South Promenade Avenue Corona: CA 91719 United States of America



A Siebe Group Company

Customer Service Phone: 800.304.6563 Fax: 800.426.0804 E-mail: infocenter@uni-line.com

© 1999 Maple Chase Company 1/99 - #150-1408

have battery back-up to present loss of programming an occiony during power outages. The battery back-up circuit small maintain all user programming for at least these months.

the the most at will have entomatic changeover constituty to allow the their most at to discourse whether the healing or cooling program should be used to control the topon temperature.

The keypad shall have a programmable keypad look to prevent to opering with the social program. The formostat shall provide a backlit display to easy institution viewing. The substitution of the formostat will provide remote socials expand to up to look temperature sensors tracklying main the mostat sensor. The thomostae shall be compact with a filter remote the formostal shall be enabled to indicate when the auxiliary stage of teathing is activated. The thermostal shall be enabled with an LED to impost compaction to oble. A finite ED shall be provided to indicate emergancy best made. The thermostal shall be equipped with a five-minute delay on break for complessor short cycle protection chang system operation to prevent compacts or damage.

Distributéd by:

http://www.thermostatsales.com

Other thermostats to check out

9500

9505

9520

9600

9610

9620

9700

9710

9720

Warning

ELECTRICAL SHOCK HAZARD. Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the off position before removing or installing any thermostat.

Warning

This thermostat must be installed only by a professional contractor familiar with air conditioning and heating systems controls and wiring.

Install only on 24V AC control systems

THIS PAGE BLANK (IISPTC)